

TECH



TPMS STARTER KIT

72-20-545

Kit Includes: 72 Service Kits • 20 Bolt-in Valves • 4 Rubber Valves
25 High Pressure Valve Caps • 25 Nickel Valve Cores



www.techtpms.com



TPMS STARTER KIT - 72-20-545

<p>72-20-503 Citroen, Fiat, Lancia, Peugeot</p> <p>Kit Qty - 8 Re Order Qty - 10 Torque - 4.25nm</p> 	<p>72-20-504 Chevrolet, Lotus, Nissan, Vauxhall, SAAB, Volvo</p> <p>Kit Qty - 8 Re Order Qty - 10 Torque - 6nm</p> 	<p>72-20-505 Renault</p> <p>Kit Qty - 8 Re Order Qty - 10 Torque - 8nm</p> 	<p>72-20-506 Volkswagen</p> <p>Kit Qty - 8 Re Order Qty - 10 Torque - 8nm</p> 
<p>72-20-507 Nissan, Renault</p> <p>Kit Qty - 8 Re Order Qty - 10 Torque - 8nm</p> 	<p>72-20-508</p> <p>Kit Qty - 8 Re Order Qty - 10 Torque - 6nm</p> 	<p>72-20-511 Jaguar, Citroen, Peugeot, Lancia</p> <p>Kit Qty - 8 Re Order Qty - 10 Torque - 8nm</p> 	<p>72-20-513 Ford, Jaguar, Landrover</p> <p>Kit Qty - 8 Re Order Qty - 10 Torque - 8nm</p> 
<p>72-20-525</p> <p>Kit Qty - 8 Re Order Qty - 10 Torque - 6nm</p> 	<p>72-20-401</p> <p>Kit Qty - 4 Re Order Qty - 10</p> 	<p>72-20-402</p> <p>Kit Qty - 4 Re Order Qty - 10</p> 	<p>72-20-403</p> <p>Kit Qty - 4 Re Order Qty - 10</p> 
<p>72-20-405</p> <p>Kit Qty - 4 Re Order Qty - 10</p> 	<p>72-20-421</p> <p>Kit Qty - 4 Re Order Qty - 10</p> 	<p>72-20-422</p> <p>Kit Qty - 4 Re Order Qty - 10</p> 	<p>72-20-512 Kit Qty - 25 Re Order Qty - 100</p> <p>72-20-516 Kit Qty - 25 Re Order Qty - 100</p> 

IMPORTANT NOTICE When replacing any TPMS service kit, please be sure to tighten each part to the correct torque settings.